

BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE



Please read this user guide before attempting to set up your awning. Follow the user guide carefully and keep for future reference.

**A copy of the user guide is also available on our website
www.maypoleltd.com**

BROADWAY POLED TAILGATE AWNING MP9561

USER GUIDE

WARNING – GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.

CARE OF YOUR AWNING

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

CONTENTS

Awning x 1

Fibreglass roof poles x 2

Fibreglass tunnel roof pole x 1

Corner steel legs x 4

Adjustable steel tunnel roof pole x 1

Groundsheet x 1

Steel canopy poles x 2

PVC ladder pegging straps x 4

Guy ropes x 4

Webbing straps x 2

Steel pegs x 22

Carry bag x 1

BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE

BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric.

NOTE – this awning is suitable for vehicles with a height range of 180cm – 210cm. It is designed for campervans with a tailgate or a barn door.

PITCHING INSTRUCTIONS

Remove the awning from the carry bag and place flat on the ground.

Pre-assemble the 4 corner steel legs and 2 fibreglass roof poles.

Insert each fibreglass roof pole into both black roof sleeves to form a cross shape.



Insert the fibreglass pole into the corner steel pole.



BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE

Insert the metal pin ring at the base of the awning into the bottom of each steel leg. Attach the canopy to the metal poles using the plastic clips.



Open the rear door of the vehicle and position the awning behind the open doors.



BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE

Hook the elasticated tunnel over the open doors so it sits in the channel between the roof and doors.

Pre assemble the adjustable steel tunnel roof pole. Insert both ends into the plastic pockets. Fully extend the pole to its maximum length. Secure the plastic clips to the pole.



FOR BARN DOOR CAMPERVANS

Pre assemble the fibreglass tunnel roof pole. Insert both ends into the plastic pockets so it is fully tensioned. This allows the rain to drain off and provides extra shape and support when using on barn door campervans.



BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE

Once the tunnel is secured over the rear doors; peg down the webbing straps at the side of the van and fully tension.



Ensure all 4 sizing straps are square and peg down all corners and sides.

Once in position; peg down all guys and tension using the adjusters provided.



It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point.

BROADWAY POLED TAILGATE AWNING MP9561 USER GUIDE

To pitch the canopy door; pre-assemble the steel canopy poles. Extend the front door and insert the top spike on each pole into the corner eyelets of the front door. Once in position guy the poles and tension using the adjusters provided.



SSOe

Technical Manager Maypole Ltd Oct 2022

Email: sales@maypoleltd.co.uk Web: www.maypoleltd.com