



**MAYPOLE**  
**SECURITY**

[www.maypole.ltd.uk](http://www.maypole.ltd.uk)

# Strongbox Hitch Lock

Ideal for braked trailers fitted with ALKO, Steelpress & Knott pressed steel hitches

**Instructions:** This hitch lock can be fitted with the caravan/trailer hitched to a towing vehicle, or unhitched, as required.



**Fig 1**

Remove the lock by inserting the key and turning clockwise until the lock body spins. Remove the lock using the key.



**Fig 2**

Slide the front plate to the open end of the housing and remove by pulling outwards.



**Fig 3**

Fit hitch lock body to hitch sideways on.



**Fig 4**

Re-fit front plate by offering it to the hitch lock body at an angle of 20 degrees matching the bottom pins to the bottom slots of the hitch-lock body. Once pins are inserted bring the front plate to a vertical position to engage all pins. Slide the plate into the closed position.



**Fig 5**

To re-fit lock rotate the key anti-clockwise whilst holding the barrel to release the catch. Insert barrel into the lock holder depressing the catch while inserting. Rotate the barrel using the key anti-clockwise until the latch clicks into place.