

**AIR ANNEXE (MP9546) FOR CROSSED
DRIVEAWAY AWNINGS (MP9544 & MP9545)
USER GUIDE**



Please read this user guide before attempting to set up your Air Annexe.

Follow the user guide carefully and keep for future reference.

**A copy of the user guide is also available on our website
www.maypoleltd.com**

AIR ANNEXE (MP9546) FOR CROSSED DRIVEAWAY AWNINGS (MP9544 & MP9545) USER GUIDE

WARNING – GENERAL SAFETY

- Not to be used in strong winds and extreme weather conditions.
- If using stepladders or a platform to set up the Air Annexe you will be working at height & should carefully follow the stepladder / platform manufacturer's safety instructions. You should not attempt to set up this Air Annexe from the ladder but only to use the ladder if required to assist people on the ground.
- **DO NOT drive with this Air Annexe attached to your vehicle.**

CARE OF YOUR AIR ANNEXE

- Allow material to dry completely before storing in the storage bag provided.
- Remove dirt with a soft sponge and warm water. DO NOT use detergent.
- DO NOT expose to sparks, flames or other sources of ignition.
- NOTE – during certain conditions moisture maybe visible on the inside of the material. This is the natural build up of condensation and should not be mistaken for leaking.

CONTENTS

Annexe x 1

Inner tent x 1

Steel pegs x 12

Guy ropes x 6

Carry bag x 1

AIR ANNEXE (MP9546) FOR CROSSED DRIVEAWAY AWNINGS (MP9544 & MP9545) USER GUIDE

BEFORE USE

Choose a clear site that is flat. Remove any sharp objects from the pitching area which could be dangerous or potentially damage the fabric or puncture the air tubes.

NOTE – this Air Annexe is only compatible with the Maypole Crossed Air Driveway Awning for Campervans (MP9544) & Crossed Air Driveway Awning for Motorhomes (MP9545).

AIR ANNEXE PITCHING INSTRUCTIONS

Remove the Air Annexe from the carry bag and place flat on the ground.

The Air Annexe can be zipped onto either side of the Crossed Air Driveway Awning. Remove the side panel of the air awning and zip the Annexe onto the side.



Connect the large adaptor to the hand pump:



AIR ANNEXE (MP9546) FOR CROSSED DRIVEAWAY AWNINGS (MP9544 & MP9545) USER GUIDE

Locate the air valve found on the air tube at the front of the Annexe. Insert the adaptor into the top cap on the air valve. Inflate the air beam to approx.6-7 PSI. Remove the adaptor from the valve and securely tighten the top cap.

WARNING: WHEN INFLATING; DO NOT EXCEED A PRESSURE OF OVER 7 PSI. IN STRONG SUNLIGHT & IN HOT TEMPERATURES REDUCE THE PRESSURE TO 4-5 PSI.



Pull from the front 2 guy ropes so the Annexe is standing vertical. The annexe should now be able to support itself.

Peg out all pegging points found at the base of the air tubes and side panels. Ensure the Annexe is taut when pegging so it forms the correct shape.



AIR ANNEXE (MP9546) FOR CROSSED DRIVEAWAY AWNINGS (MP9544 & MP9545) USER GUIDE

Once in position; peg down all of the guy ropes attached to the Annexe. It is recommended each peg is driven fully into the ground at an angle of 45 Degrees away from the pegging point.



To deflate the air tubes; unscrew the bottom cap on the air valve for the air to be released. **WARNING – Be aware of sudden loud noise caused by air escaping when deflating.**

INNER TENT PITCHING INSTRUCTIONS

Remove the inner tent from the bag and lay flat on the floor with the ground sheet facing the floor. Ensure the mesh door faces the internal entrance of the awning.

Attach the 2 bottom rear buckles:



AIR ANNEXE (MP9546) FOR CROSSED DRIVEAWAY AWNINGS (MP9544 & MP9545) USER GUIDE

Attach the elasticated toggles to the rear air beam. Then attach the top 2 front buckles:



Peg out the 2 pegging points found at the front of the inner tent.

The front door can zipped closed or rolled and held with the side straps:



SSOde

Technical Manager Maypole Ltd November 2021

Email: sales@maypoleltd.co.uk

Web: www.maypoleltd.com